

Thank you for buying our rear blinds!

Here you will find a guide how to install them.

Please note that the blind slats are rolled up. Keep them tight in the hand when you unpack them so they don't unwind what can lead to damage.

The blind slats are already packed from under to top. So PLEASE do not mix up the blinds.

Some cars, like Jetta 2 / Golf 3 have a first blind (under) that is a bit smaller compared to the second. This is no mistake.

First of all, you need to install the brackets. Normally, the best position is about 10 to 15cm measured from the left and right side of the window. Make sure the width between the 2 brackets is the same above and below.



Push the 4 clips between rear window and seal. Some seals are really tight. Heating up with a heat gun can help for sure!



Now the brackets can be mounted by fastening the 4 delivered M5 nuts. For types like for example BMW E30 and Jetta, it can be helpful to mount the brackets (underside) to the clips before you insert these clips between window and seal. These types of cars have the parcel shelf a bit higher and this makes it difficult to access the nuts.



There are several ways to mount the blind slats. We suggest to install the top and bottom one and range these so the distance left and right is the same. Now you can use tape or cord to guide the other slats to the perfect position



For cars with glued rear windows, clips must be mounted like this.

